

WRAPPING

TABLETS & BARS

wrapping machines for a wide range of chocolate tablets and bars

SM MOK speed up to 350 ppm

One-step rapping machine for small chocolate bars and tablet in Envelope or Wallet style with single or double wrapping materials.

- The machine can be equipped even for chocolate products in Bunch or Double twist style.



TW RL speed up to 180 ppm

One-step wrapping machine for chocolate bars and tablets in envelope style with single or double wrapping material fed from reel, closed by hot melt glue.



TW Synchrono speed up to 350 ppm

One-step wrapping machine for chocolate bars and tablets in envelope style with single or double wrapping material fed from reel, closed by hot melt glue. The machine is suitable for a wide range of product, from small bars up to large tablets.



standard features

- Suitable for a wide range of tablets and bars
- Style and/or format CHANGE OVER less than 45 min
- HMI by color graphic Touch Screen
- No Product - No Paper system device
- High quality wrapping thanks to dedicated folding box
- Wrapped product outfeed on belt
- Gently and positively handling of product and wrapping material
- Product always under operator control during both the feeding and the wrapping sequence
- Good accessibility, easy cleaning, maintenance and size change-over operations.

optionals

- Automatic splicer for aluminium
- Spliced product reject device
- Date coder integration
- Hot glue dispenser

TW F speed up to 150 ppm

One-step wrapping machine for chocolate bars and tablets with single wrapping material, either precut paper in envelope style or precut cardboard closed by hot melt glue.

- Suitable for connection to up-stream flowpacking machine
- Suitable for multi-pack of wrapped finger bars



TW MR speed up to 150 ppm

One-step wrapping machine for chocolate bars and tablets in envelope style with double wrapping material, inner alufoil fed from reel and outer precut paper closed by hot melt glue.



TW Linear speed up to 150 ppm

Two-step wrapping machine for chocolate tablets. First step with alufoil sealed on 3 sides; Second step either with paper in envelope style or banderole or cardboard closed by hot melt glue.

